


PRODUCT NAME: James Table Lamp

ITEM NUMBER: LA166

DIMENSIONS OF ITEM ASSEMBLED: 29"H x 7 7/8"W x 18 1/4"D



## IMPORTANT SAFETY INSTRUCTIONS:

- This Lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fully fit in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
- These Assembly Instructions are provided for your safety. It is important that they are read carefully and completely before assembling this Lamp.
- This product must be installed with the applicable installation code by a person familiar with the construction and operation of the product.
- This Lamp has been rated for up to 60 Watt MAX Type A or 13 Watt CFL Bulb (NOT Included).

## WARNING:


- Deviation from these Assembly Instructions may result in a risk of fire or electric shock.
- To reduce risk of fire, electrical shock, or personal injury, always turn off and unplug Lamp and allow it to cool prior to replacing the bulb.
- Do not touch the bulb when the Lamp is turned on. Do not look directly at the lit bulb.
- Keep flammable material away from the lit bulb.

**NOTE:** Remove all parts and hardware from the box along with any plastic protective packaging and carefully lay all the parts out on a clean, flat surface.

DO NOT discard any contents until after assembly and installation is complete to avoid accidentally discarding small parts or hardware.

Recommended Location for Use: Dry Environment


Assembly Time: 10 Minutes




## PARTS

Check to make sure you have the following:


INCLUDED:




1- Lamp Fixture (A)




1- Shade (B)



1- Stem (C)



1- Clip (D)




1- Base (E)

NOT INCLUDED:



1- 60 Watt Max  
Type A Bulb




1- Pad (F)

NOTE: Before starting assembly of this Lamp, be sure it has been unplugged.  
Turning the switch off is not sufficient enough.


**STEP 1:**

Screw the Stem (C) onto the Lamp Fixture (A) and the Base (E), tightly. Slowly pull the wire out of the bottom base.



**STEP 2:**


Turn the Base (E) upside down and run the wire through the Clip (D). Close the arm of the Clip to lock the wire into place.



NOTE: Before starting assembly of this Lamp, be sure it has been unplugged.  
Turning the switch off is not sufficient enough.


**STEP 3:**

Stick the Pad (F) onto the bottom of the Base (E).



**STEP 4:**

Unscrew the socket ring from the socket. Attach the Shade (B) to the Lamp Fixture (A), then screw the socket ring back into place. Screw in the Bulb. This Lamp has been rated for up to a 60 Watt MAX Type A or 13 Watt CFL Bulb (NOT Included).



**Cleaning & Care:**

To clean, wipe the Fixture with a soft, dry cloth.  
Avoid the use of harsh or abrasive  
chemicals as they may damage the finish