


PRODUCT NAME: Xander Task Lamp

ITEM NUMBER: LA234

ASSEMBLED DIMENSIONS: 28"H x 7 1/2"W x 7 1/2"D



IMPORTANT SAFETY INSTRUCTIONS:

- This Lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fully fit in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
- For your safety, please read instructions carefully and completely before beginning assembly or installation.
- Product must be installed according to applicable code(s) by a person familiar with its construction and operation.
- This Lamp rated up to 60 Watt MAX Type A INCANDESCENT Bulb (NOT Included).

WARNING:

- Deviation from assembly instructions may cause risk of fire or electric shock.
- To reduce risk of personal injury, always turn off fixture and allow bulbs to cool prior to replacement.
- Do not touch or look directly at illuminated bulbs.
- Keep flammable material away from illuminated bulbs.


Remove all parts, hardware and protective packaging from carton and carefully arrange on a clean, level surface.

NOTE: To avoid accidentally discarding small parts or hardware, retain all carton contents until after assembly and installation are complete.


Recommended Location for Use: Dry Indoor Environment

PARTS


Check to make sure you have the following:



1- Metal Shade




1 - Socket Ring



1 - Fixture Body

NOT INCLUDED:



1 - 60 Watt Max
Type A Incandescent Bulb
*LED may be used


NOTE

- The Qi Wireless charger works with Qi enabled devices such as Samsung Qi enabled Smartphones and Apple iPhone 8 or above.
- Qi Wireless Pad: Input: 5V/2A Output: 5W MAX
- Be certain no other objects are on charging pad. Phone case may impede charging. Remove case if necessary.

NOTE: Unplug lamp prior to installation or removal. Turning off switch is not sufficient.


STEP 1: ATTACH SHADE

Gently remove Socket Ring (B) from Socket. Slide Shade (A) over Socket and replace and tighten Socket Ring by turning clockwise. NOTE: Do not over tighten.



STEP 2: INSTALL BULB

Gently turn bulb into socket. Socket has been rated up to a 60 Watt MAX Type A INCANDESCENT Bulb (NOT Included).
*NOTE: If you need more brightness than an incandescent 60W switch to a higher equivalent LED or CFL bulb, which can provide 4-5 times the illumination (lumens) without exceeding your fixture's maximum wattage.



STEP 3: CHARGING

USB port also available for charging a device. Do not overcharge.

NOTE: To protect and preserve battery memory, do not store or leave phone on Qi charger for long periods.

Cleaning & Care:

To clean, wipe the Fixture with a soft, dry cloth.

