# BALLARD DESIGNS

PRODUCT NAME: Cyrus 2 Door Console Cabinet
ITEM NUMBER: SK091
ASSEMBLED DIMENSIONS : 36"H x 28"W x 18"D

⚠ **Prevent accidentally discarding small parts or hardware. Retain all carton contents until assembly and installation are complete.**

PRODUCTS ARE NOT INTENDED
FOR COMMERCIAL USE.
UPDATED: 6-24-2021

MADE IN INDONESIA

⚠ Assemble in location for intended use.

Ltr.	Qty.	Hardware Included
A	8	**Shelf Supports** (Ship installed with Shelves inside Cabinet)
B	2	**Wall Anchoring** (Anti-tip) Kits (See page 3)

REQUIRED TOOLS:
Phillips Screwdriver
-Two person assembly suggested.

Remove all parts, hardware and protective packaging from carton and carefully arrange on a clean, level, padded surface.

WARNING
**Tip-Over Hazard**
ANCHORING HARDWARE INCLUDED
Serious or fatal crushing injuries can occur from a furniture tip-over
Prevent tipping accidents. Anchor your furniture.

Ltr.	Qty.	Components
C	1	Cabinet (C)
D	2	Shelves (D) (Ship installed inside Cabinet)

STEP 1: Adjust Shelves if desired. Remove Shelf (D), remove and relocate Shelf Supports (A), set Shelf level upon Supports.

STEP 2: Console is equipped with Rotary Levelers. If necessary, adjustments may be made by carefully lifting applicable corner and turning Leveler clockwise/counterclockwise.

(D)
(A)

Adjust Levelers BEFORE anchoring unit to wall.

Customer Service: 800-367-2810
Online: www.ballarddesigns.com

Cleaning and Care
Periodically dust with a soft, dry cloth.
Prevent finish damage: do not use alchohol based cleaners or polishers. Promptly remove spills.

WALL ANCHORING HARDWARE (ANTI-TIP)

Ltr.	Qty.	Hardware Included	
A	4		Small Screw
B	4		Large Screw
C	4		Bracket
D	2		Retention Belt

WARNING
Tip-Over Hazard

Serious or fatal crushing injuries can occur from a furniture tip-over
Prevent tipping accidents. Anchor your furniture.

1. Place furniture against wall at desired location then locate and mark a Wall Stud behind unit.
2. Corresponding to Stud location, attach one Bracket (C) to back of unit using Small Screws (A).
3. To keep hardware out of view after installation, attach remaining Bracket (C) **INTO WALL STUD** with Large Screws (B) 2 inches below Bracket attached to back of unit.
4. Move unit into place, align Brackets then connect both using Retention Belt (D).
5. Confirm Belt is securely laced and locked.

⚠ **WALL BRACKET MUST BE ATTACHED TO WALL STUD**

(A)
(B)
(C)
(D)
WALL STUD