
# BALLARD DESIGNS.




PRODUCT NAME: Sanders Sideboard

ITEM NUMBER: SF100

ASSEMBLED DIMENSIONS: 34.5"H x 54"W x 20"D



**SHELVES:** Determine location for Shelf Frame (D) then insert Shelf Supports (A) into corresponding pre-drilled holes. Set Shelf level upon supports then set Glass (E) level into frame.




REQUIRED TOOLS: Phillips Screwdriver

Ltr.	Qty.	Hardware Included	
Α	4	□ Shelf Supports	
В	2	Wall Anchoring (Anti-tip) Hardware See Page 3	

Ltr.	Qty.	Components		
С	1	Sideboard (C)		
D	1	Shelf Frame (D)		
Е	2	Glass (E)  Tempered Glass  Avoid Bumping/Impacting Shelf Edges or Corners		

**LEVELERS:** Console equipped with Rotary Levelers. If necessary, Sideboard may be adjusted by carefully lifting applicable corner and turning Leveler clockwise/counterclockwise.



**LIGHTS:** Integrated LEDs. Not replaceable. DC 12-24V 6A. ON/OFF Rocker Switch inside right compartment.



## SURGE PROTECTION Protect delicate LEDs from power

Protect delicate LEDs from power surges and lightning strikes.
Plug lights into a Surge Proctector

NOTE: Connection box on light set designed for adding lights in optional Hutch (Sold Separately).

PRODUCTS ARE NOT INTENDED FOR COMMERCIAL USE. UPDATED: 8-12-2022



#### Cleaning and Care

Periodically dust with a soft, dry cloth.

Prevent finish damage: do not use alchohol based cleaners or polishers. Promptly remove spills.

MADE IN ITALY Page 1 of 2


### WALL ANCHORING HARDWARE (ANTI-TIP)

Ltr.	Qty.	Hardware Included		
A	2	<11111111111111111(%)	Large Screw	
В	2	<uut< td=""><td>Small Screw</td></uut<>	Small Screw	
С	4		Bracket	
D	2		Retention Belt	



#### Installation:

- 1. Place furniture against wall at desired location then locate and mark a Wall Stud behind unit.
- 2. Corresponding to Stud location, attach one Bracket (C) to back of unit using Small Screw (B).
- 3. To keep hardware out of view after installation, attach remaining Bracket (C) **INTO WALL STUD** with Large Screw (A) 2 inches below Bracket attached to back of unit.
- 4. Move unit into place, align Brackets then connect both using Retention Belt (D).
- 5. Confirm Belt is securely laced and locked.



Customer Service: 800-367-2810 Online: www.ballarddesigns.com