

BALLARD DESIGNS.



PRODUCT NAME: Sanders Hutch ITEM NUMBER: SF101 (SF099)

ASSEMBLED DIMENSIONS: 45"H x 44"W x 15"D



PRODUCTS ARE NOT INTENDED FOR COMMERCIAL USE. UPDATED: 8-24-2022

MADE IN ITALY Page 1 of 4

Assemble in location for intended use.

Ltr.	Qty.	Hardware Included	
А	8	Shelf Supports	
В	3	Connector Brackets	
С	12	≪⊞⊞⊞ Screws	
D	2	Wall Anchoring (Anti-tip) Hardware See Page 4	


REQUIRED TOOLS:

Phillips Screwdriver

-Two person assembly suggested.

Remove all parts, hardware and protective packaging from carton and carefully arrange on a clean, level, padded surface.







Cleaning and Care

Periodically dust with a soft, dry cloth.


Prevent finish damage: do not use alchohol based cleaners or polishers. Promply remove spills.




Customer Service: 800-367-2810 Online: www.ballarddesigns.com

Assemble in location for intended use.

STEP 1: Assemble Sanders Sideboard (SOLD SEPARATELY) and set in place. Carefully lift Hutch (E) and place onto top of Sideboard. Center Hutch then align back edges. Place Connector Brackets (B) on back as illustrated (right/center/left) and secure using Screws (C).



STEP 2: Determine location for each Shelf Frame (F) then place Shelf Supports (A) into corresponding pre-drilled holes. Carefully set Shelf level upon supports then set Glass Panels (G) into frame. **LIGHTS:** Plug into light system included with Sideboard. Switch is inside Sideboard in right compartment.



Page 3 of 4

Online: www.ballarddesigns.com

WALL ANCHORING HARDWARE (ANTI-TIP)

Ltr.	Qty.	Hardware Included		
A	2	<111111111111111(%)	Large Screw	
В	2	<uut< td=""><td>Small Screw</td></uut<>	Small Screw	
С	4		Bracket	
D	2		Retention Belt	



Installation:

- 1. Place furniture against wall at desired location then locate and mark a Wall Stud behind unit.
- 2. Corresponding to Stud location, attach one Bracket (C) to back of unit using Small Screw (B).
- 3. To keep hardware out of view after installation, attach remaining Bracket (C) **INTO WALL STUD** with Large Screw (A) 2 inches below Bracket attached to back of unit.
- 4. Move unit into place, align Brackets then connect both using Retention Belt (D).
- 5. Confirm Belt is securely laced and locked.

