


PRODUCT NAME: Amalfi Double Chaise

ITEM NUMBER: SO463

DIMENSIONS OF ITEM ASSEMBLED: 35 1/2"H x 51"W X 80 3/4"D















PRODUCTS ARE NOT INTENDED
FOR COMMERCIAL USE.








Updated: 6/14/2017

MADE IN CHINA

Page 1 of 5


TOOLS NEEDED: Adjustable Wrench. Possible 2 person assembly.

Ltr.	Qty.	Hardware Included		Ltr.	Qty.	Hardware Included	
A	5		Large Bolts (M8*55)	G	4		PVC Washers (M8)
B	10		Large Washers (M8)	H	2		Allen Bolts (M6*15)
C	7		Large Lock Washers (M8)	I	2		Small Lock Washers (M6)
D	7		Nuts (M8)	J	2		Small Washers (M6)
E	7		Nut Caps (M8)	K	2		Wheel Cap
F	2		Small Bolts (M8*40)	L	1		Allen Wrench


Ltr.	Qty.	Components	
M	1		
N	2		
O	1		
P	1		
Q	1		
R	1		
S	2		
			

WARNING: Aluminum is a soft metal and over-tightening will strip the thread or break the part.

STEP 1: Flip the Bed (M) of the Chaise onto its left side to attach the Right Arm (P). Attach the Right Arm by lining up the front and back holes in the Right Arm to the holes in the Bed. Use an adjustable wrench to secure the Right Arm with a Large Bolt (A), Large Washer (B), Large Lock Washer (C), Nut (D) and Nut Cap (E).




STEP 2: Flip the Bed (M) onto it's right side and insert the Axel Rod (R) into the back, lower hole in the Right Arm (P).




WARNING: Aluminum is a soft metal and over-tightening will strip the thread or break the part.

STEP 3: First attach the Left Arm (Q) to the Axle Rod (R). Next, attach the Left Arm (Q) to the Bed (M) by lining up the front and back holes in the Left Arm to the holes in the Bed. Use an adjustable wrench to secure the Left Arm with a Large Bolt (A), Large Washer (B), Large Lock Washer (C), Nut (D) and Nut Cap (E).




STEP 4: Place Wheels (S) onto the Axle Rod (R) with the plastic ring on the Wheel hub towards the inside. Secure with Small Washers (J), Small Lock Washers (I), and Allen Bolts (H) using the provided Allen Wrench (L). Last, push the Wheel Cap (K) into the Bolt hole to cover the hole.



WARNING: Aluminum is a soft metal and over-tightening will strip the thread or break the part.

STEP 5: Place the Back Adjuster (O) into a set of slots on the back of the Arms. Attach both Backrests (N) first to the center section of the Bed (M) with a Large Bolt (A), two Large Washers (B), two PVC Washers (G), a Lock Washer (C), a Nut (D) and a Nut Cap (E). Attach the Backrests to each side of the Bed using a Small Bolt (F), two Large Washers (B), a PVC Washer (G), a Large Lock Washer (C), a Nut (D) and a Nut Cap (E).



Cleaning & Care:

Please do not use acid or alkaline washing liquid to clean this item.

IMPORTANT:

Aluminum is soft metal and over-tightening will strip the thread or break the part.